

CUBE Remote Player Troubleshooting Guide

ISSUE	ACTION
No power to unit	Check to ensure power adapter is connected to Cube and reliable hydro source
Messages not playing	Check to ensure 3.5mm audio cord is connected to Cube and to the telephone system
Unit not receiving new messages	Check to ensure that Cube is connected to internet port via supplied ethernet connection or wifi